


Snambol

Product model:CP5 mini



Product Manual

Shenzhen ZO Video Technology Co., Ltd.

1: Product Highlights




Nimble & Compact



Zoom Control

Flash
Connection3 Hours
Battery LifeShooting
Mode Switch30m Range
40ms Delay

2: Product Design



1 Power/Brightness

2 Press: Enlarge screen | Press & Hold: Zoom out
In shooting switch mode: press = move left3 Press: Screen mirroring | Press & Hold: Zoom in
In shooting switch mode: press = move right

4 Press: Shooting control | Press & Hold: Enter shooting switch mode

5 Battery Indicator / Reset Hole 6 Type-C Port

Press to turn on, Press & Hold to turn off.
Press to adjust brightness after power on.

Press to zoom in Press to mirror, Press & Hold to rotate

Press to control the shutter

(Please use a power adapter of 5V=2A or higher for charging.)

Battery status light indicators.

Connected to usb power: Flashing Red Battery charging

Flashing Green Battery fully charged

Not connected to usb. Light off No status indicated

3: Package List



1 CP5 mini



2 User Manual



3 Type-C Cable



4 Lanyard

4: Parameters

Model	CP5 mini
Screen Resolution	480*800P
Screen Size	2.2-inch LCD
Ports	Type-C Port
Power Supply	Type-C 5V/ Built in Battery
Power Consumption (Typical Value)	<1.5W
Weight	62g
Dimensions	68*38.2*19.5mm
Bluetooth Shutter Control	Available
Transmission Frequency	2.4G / 5GHz
Transmission Latency	40ms
Receiving Sensitivity	-85dBm

For further assistance
please refer to the After-Sales Service Card

Tel: +86 0755-21004986

Web: en.shimbol-tech.com

Add: 2C, 2nd Floor, 8th Building, Longbi Industrial Park, Dafalu No. 27, Bantian Street,
Longgang District, Shenzhen, Guangdong Province, China
Shenzhen ZO Video Technology Co., Ltd.

5: Apple Connection Steps

1、Swipe down from the upper right corner of the device to open the control center



2、Open "Screen Mirroring" to connect CP5_mini_XXXXXX




6: Android Connection Steps

1、Swipe down from the upper right corner of the device to open the control center



2、Open the "Screen Mirroring/Wireless Projection" to connect CP5_mini_XXXXXX




7: SAMSUNG Connection Steps

1、Swipe down from the upper right corner of the device to open the control center



2、Open the "Device Control" to connect CP5_mini_XXXXXX



8: Shutter Control & Shooting Mode Switch

1、Turn on Bluetooth and connect to CP5_mini_XXXXXX



2、Android:
Control shooting & switch modes via Bluetooth
iOS:
Switch modes: Enable Zoom (Settings → Accessibility)



Press the shutter button to control the shutter

9: Hazardous Substances in Electronic Products

Component Name	Toxic and Hazardous Substances or Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr6+)	Polybrominated Biphenyls (PBBs)	Polybrominated Diphenyl Ethers (PBDEs)
Screen	○	○	○	○	○	○
Shell	○	○	○	○	○	○
Circuit Board	○	○	○	○	○	○
Wires	○	○	○	○	○	○
Packaging Material	○	○	○	○	○	○
Metal	○	○	○	○	○	○
Battery	○	○	○	○	○	○

- : Indicates that the content of the hazardous substance in all homogeneous materials of this component is below the limit requirements specified in GB/T 26575-2011.
- ✗ : Indicates that the content of the hazardous substance in at least one homogeneous material of this component exceeds the limit requirements specified in GB/T 26575-2011.

According to the Chinese electronic industry standard SJ/T 11364-2014 and relevant government regulations, this product and some of its internal or external components may carry an environmental protection use period label. The use period label may vary depending on the components and their manufacturers. The use period label on the components takes precedence over any conflicting or different environmental protection use period labels on the product.

10: Safety Precautions

1. This product is designed to operate in environments with temperatures between 0°C and 35°C, and should be stored at temperatures between -20°C and 45°C. Extreme temperatures can affect the product's performance and may damage both the product and the battery. Please avoid charging outside the 0°C to 35°C range to prevent reduced battery performance or damage.
2. Please do not place this product or battery near heating devices, cooking appliances, or pressure vessels (such as microwaves, induction cookers, ovens, heaters, pressure cookers, water heaters, gas stoves, etc.) or inside them, as this may cause the battery to overheat and potentially explode.
3. User must use certified and compatible chargers, data cables, and batteries. Using unapproved adapters or cables may result in electric shock, fire, explosion, or other hazards.
4. This product is not designed to be waterproof and does not support immersion in liquids. Please do not use this product in or near liquids to avoid device damage.

Warning: the following actions may pose safety risks to the battery and lead to safety issues during normal use of this product:

1. Disassembling the battery yourself.
2. Applying excessive pressure or puncturing the product.
3. Placing the phone in a microwave, near a flame, or close to other heat sources.
4. Allowing the product to come into contact with water or other liquids.

Battery Tips:

- 1- Increasing screen brightness will reduce battery runtime.